



KEYFOB
SMART REMOTE SERIES
#SmartAlarmControl



DESCRIPTION

KeyFob is a compact, battery-powered, Zigbee compatible device that allows you to **ARM & DISARM** the smart security & alarm systems in your home at just a click of a button.

After a quick setup, the KeyFob is compact, easy to carry and sends signals to your security systems **up to 100m away** from your house without any Internet.

KEYFOB OPERATION	FUNCTIONALITY
Away Mode	A click activates the selected sensors that you want to ARM when you are AWAY from home
Stay Mode	A click activates the selected sensors that you want to ARM when you are AWAY IN your house
Disarm Mode	A click DISARMS all the activated sensors IN your home
Panic Mode	A click sends message in the format "[YOUR HOUSE NAME] HOGAR ASK FOR HELP" to your registered email id.

ARM & DISARM YOUR SECURITY SENSORS AT A CLICK

ZIGBEE COMPATABILITY

EASY TO CARRY

DIRECT REMOTE ACCESS UPTO 100m

APP CONTROL

SOS

SPECIFICATIONS

Model No.	HSE-KFB-001
Battery Type	CR2025
Power Supply	DC 3V
Operating Current	<= 7µA
Dimension	57 x 31 x 11 mm
Operating Temperature	-10 °C - +55 °C
Transmission Distance	<=100 m (in open area)
Housing material	ABS Plastic
Humidity	<=80% (non-condensing)
Wireless Protocol	ZigBee 3.0
Radio Frequency	2.4 GHz

ADDING KEYFOB TO YOUR SMART HOME

- Open the Hogar SE App and go to **"Rooms"** & then **"All Devices"**. Click on "+" Button and select **"KeyFob"**. Follow the prompts on your App for subsequent steps.
- Use a Pin & hold the **"Reset Button"** for **5 seconds**.
- The **LED** starts blinking **GREEN** indicating the KeyFob has entered into **"Network Pairing Mode"**
- On successful pairing, the **LED** blinks **RED** for **3 seconds** and you receive a message on your Hogar SE App.
- If the pairing is not successful, the **LED** turns **OFF** from **GREEN**. Attempt again to trigger **Network Pairing Mode** by using the pin.

CONFIGURING SENSORS TO "STAY" & "AWAY" MODE

- Open the Hogar SE App and go to Settings.
- Click on **"Alarm Modes"** and then select:
- **STAY** => Select the sensors that need to be Armed when you are **IN** your house.
- **AWAY** => Select the sensors that need to be Armed when you are **AWAY** from your house.

NOTE: Once configured, you can **ARM & DISARM** the selected sensors in **STAY, AWAY & DISARM** modes both through the KeyFob as well as a click from the **Security Section** of your Hogar SE App.

WARRANTY

Hogar Provides Limited Warranty of 18 months on every product.

ENQUIRY

For Orders/Details, kindly reach out to us at info@hogarcontrols.com



Scan QR code for more details on warranty and sales enquiries